

UNPACKING INSTRUCTIONS

Thank you for your continued interest in our products. Canadian Solar is committed to provide high quality and high performance solar modules to assist your PV business growth. This document provides unpacking instruction to our vertical packaging solution for solar modules.



Disconnect the three middle packing belts.

①



②



Remove the upper cover of the box, then disconnect the vertical and upper horizontal packing belts, leave the bottom one.

Adhesive tapes

Adhesive tapes



Bend down the front cover along the middle cutting line.

④



③

Hook & Loop of front cover



Tear apart the Hook & Loop from the upper of front cover.



Before

After

⑤



⑥



Two workers take out the module from the box. Then repeat step 5 and 6 to take out the other modules one by one.

Two workers peel off the adhesive tapes at the two ends of one module once a time, and the tapes need to be rolled up as above picture.

Attention:

- The modules are vertically packed in the box.
- Please place the pallets on a flat area before unpacking.
- Please wear gloves to prevent your hands from injuring.
- Do not unpack the whole box before taking out all the modules.
- Two workers are required to unpack modules from the packing box. When handling modules always use both hands.

CSI Solar Co., Ltd.

199 Lushan Road, SND, Suzhou, Jiangsu, China, 215129
support@csisolar.com, www.csisolar.com